

RECKMANN

operation manual

UDs
hydraulic furling system
aluminium foils
rod
RT



Stand: 20 January 2011

Copyright by
Reckmann Yacht Equipment GmbH
Siemensstr. 37-39
D-25462 Rellingen

1	Introduction	5
1.1.1	Packing list	5
2	Introduction	8
2.1.1	How to use this manual	9
2.1.2	Important remarks	10
2.1.3	Toggle	12
2.2	Maintenance of the furler	14
2.2.1	Maintenance to be carried out by the customer	14
2.2.2	Maintenance to be carried out by a Reckmann service partner	14
3	Product description	15
3.1	components of the manual backup drive	15
4	Assembling the furling unit	16
4.1	Calculation of stay and foil length	17
4.2	Tools required for assembly	20
4.3	Foil size	20
4.4	Foil assembly from R10 up to R40	21
4.4.1	Preparation of the top cap	21
4.4.2	Shortening the top foil	22
4.4.3	Shortening the top hose	23
4.4.4	Assembly of bushings and spacer tubes	24
4.4.5	Foil assembly / split foil connectors	26
4.5	Installation of the foil reinforcement (optional)	28
4.5.1	Preparation of the headstay	28
4.5.2	Reinforcement assembly	30
4.6	Foil assembly R50, R5 up to R8	34
4.6.1	Shortening the top foil	34
4.6.2	Preperation of the top cap	35
4.6.3	Sliding the top foil onto the stay	36
4.6.4	Fasten a connector on the stay	37
4.6.5	Inserting a threaded plate	38
4.6.6	Sliding the remaining foils onto the stay	39
4.6.7	Assembly of the feeder section	41

4.7	Assembly of halyard swivel and sail feeder for foils R10 up to R50	42
4.8	Assembly of the top cap	43
4.9	removing the hydraulic motor	44
4.10	Installation of the furler to the deck	46
4.11	Assembly of stay, foils and furler.....	47
4.12	Connection of stay and furler	48
4.13	Connection of foils and furler.....	50
4.14	Configuration of the head	55
4.15	Valve configuration of the motor.....	57
4.16	Connection of the hydraulic hoses to the real time adjuster	59
4.17	Stay adjustment with the real time adjuster	60
4.17.1	Stay adjustment in relation to halyard tension	61
4.18	Installation of the hydraulic manual backup system.....	64
4.19	Operation of the manual backup	69
4.20	Additional installation information	70
4.21	Piston position indicator (as an option)	71
4.22	Pressure sensor (as an option)	72
5	specifications	76
5.1	Reckmann aluminium foil sections.....	79
6	Dealer network and service stations.....	80
7	Index	86

1 Introduction

1.1.1 Packing list UDs

Date

Customer

Dealer

Order number

Type: UDs

headstay type:	-	size (mm, -):	
headstay length: D=	mm	unshortened foil length P:	mm
rod collets/			
swage terminal:	1 pc	topterminal:	
halyard swivel:	1 pc	___ - shackle	pcs
tack slider		Shackle size:	
Manual:	1 pc	foil type (R/S):	

1	gear unit with hydraulic motor
—	rod link with rod nose / jaw fitting
1	manual backup system including pump
1	foil adapter
1	piston position indicator
—	long bottom bushing

Introduction

1 Feeder section*	<input type="checkbox"/>	3000 mm	<input type="checkbox"/>	5980 mm
Standard section	<input type="checkbox"/>	3000 mm	<input type="checkbox"/>	5980 mm
Standard section		1500 mm		
Top section		_____ mm		

*length without furler spline and sliding tube

R10 up to R40

Hose 200 mm

Hose 340 mm

Hose 500 mm (red marked)

Hose 600 mm

Hose 1740 mm

Top hose _____ mm

R50 and R5 up to R8

Spacer tube 240 mm (at some sizes slotted)

Spacer tube 1660 mm (at some sizes slotted)

Splice bearing with two screws (at some sizes split)

Bottom bushing

Bearing for foil reinforcement (at some sizes split)

Bottom foil reinforcement

Foil connectors (at some sizes split)

Delrin bearings (2 spares up to R40), (at some sizes split)

SS inserts for foil connectors (1 spare)

Screw for foil connectors (2 spares)

1 Top cap with screws (split)

1 Bottom threaded plates with screws

1 Sail feeder

_____ Key for stay adjustment

1 Set socket wrenches

_____ Winch handle

Additional equipment:

Packed by

2 Introduction

Dear Reckmann customer,

With the UD's reefing system you have purchased the latest reefing system which you can rely on. This unit is manufactured using the latest technical innovations and uses the best materials. It is a successful combination of design, performance and safety. We are confident that the UD's reefing system will provide you with enjoyment for many years.

2.1.1 How to use this manual

Read this manual carefully before assembly and operation of your Reckmann gear.

Points that need additional attention will be marked in the following way:

**Note!**

This sign marks points which need special attention.

**Warning!**

This sign marks the risk of injuries or other significant danger.

**Tip**

this triangle marks useful tips.

2.1.2 Important remarks

After your furling system was installed accordingly to this manual, we recommend to read the following notes carefully before you set your furling system into operation.



Note!

Improper use according to this manual of the furler may cause loss of warranty.
Consult a Reckmann service partner in any case of problems.



Warning!

Any modification or damage may influence the safe operation of the furler.

Please make sure that the furling system is in a well condition according to this manual.



Warning!

Adjusting with load on the sheet may damage the profile.

Adjust only when sheet is unloaded.

For stay tensioning purposes, your Reckmann furling gear is equipped with a hydraulic real time adjuster. The adjuster pulls the stay in relation to the foils. This means that the distance between the tack point at the furler and the halyard sheave / or lock varies during stay adjustment:
Releasing the stay: distance gets longer – luff is tensioned
Tensioning the stay: distance gets smaller – luff becomes loose

Please make sure that the distance change cannot damage any items by releasing the halyard or easing the cunningham before the real time adjuster is used. Please refer to the corresponding chapter of this manual.

**Note!**

Risk of damages of the sails during real time adjuster operation. Please refer to the corresponding chapter of this manual.

Release the sheet before the sail is furled.

**Warning!**

Furling the sail against a tensioned sheet may cause damages of the furler.
Release the sheet before you start furling the sail.

**Tip**

Too low halyard tension may cause a halyard wrap.
A halyard wrap blocks the furling gear and may cause damages of the foils.
Make sure that the halyard is under sufficient tension.

**Tip**

The genoa halyard has to be equipped with a swivel shackle. If the halyard gets twisted around the foil, the functioning of the furler will be impaired.
As mentioned above, the swivel shackle enables the halyard to lose its twist.



Tip

Too low headstay tension causes sag of the headstay which reduces the performance of the boat.

Please make sure that your headstay tension is sufficient.

2.1.3 Toggle


Please ensure that a toggle is installed at the top stay end. If there is no toggle installed, bending loads in the top terminal may cause the failure of the stay due to fatigue.



Warning!

Forestays without top toggles could break due to fatigue.

Make sure that a top toggle is installed.



**Note!**

The deck flange of the furler is not watertight. To avoid flooding of the boat, the furler has to be installed in a drained compartment.

The Reckmann furling unit is installed directly to the deck. The deck has to tolerate the entire stay load.

**Warning!**

Make sure that the deck is strong enough to carry the entire stay load.

**Note!**

Luff tape remaining in the sail feeder at a fully hoisted sail may damage the feeder. Make sure that the luff tape ends above the feeder at a fully hoisted sail.

2.2 Maintenance of the furler

To keep the furler in a good optical and technical condition, a regular service is required. Maintenance of the furler consists of two basic points:

- Regular maintenance by the customer
- Regular Service performed by one of our service partners



Tip

Proper operation can only be ensured by regular service. Make sure that the maintenance plan of your furler is carried out carefully.


2.2.1 Maintenance to be carried out by the customer

Clean your furling gear regularly. Wash carefully all salt from the furler. Stainless steel parts can be treated with special care product. Additional for all electric and hydraulic furling units, the function of the manual backup drive and the condition of all hydraulic hoses / electric wires should be checked regular.

2.2.2 Maintenance to be carried out by a Reckmann service partner

To ensure the safe and proper operation of the furler, it has to be serviced every five years by an authorized Reckmann service partner. A table of all authorized Reckmann service partners can be found at the end of this manual or at www.reckmann.com


3 Product description



- | | | | |
|---|---------------------------|----|-----------------|
| 1 | Foil adapter | 7 | Hydraulic ports |
| 2 | Tack ring | 10 | Motor |
| 3 | Spherical deck bearing | 12 | Rod link |
| 4 | Gear unit | | |
| 5 | Adjuster | | |
| 6 | Piston position indicator | | |

3.1 components of the manual backup drive


Assembling the furling unit



- | | |
|--|-------------------------------------|
| 1 Socket for winch handle | 2 Deck flange |
| 3 Bolt holes for deck attachment | 4 Pump flange box |
| 5 Allen key for pump volume adjustment | 6 Socket for pump volume adjustment |
| 7 Oil fill cap | 8 Backup pump |
| 9 Hose connectors with integrated check valves | |

4 Assembling the furling unit

4.1 Calculation of stay and foil length



Assembling the furling unit



Unit	Swivel	Stay	Foil	AUD	X *	Y **	T	LS *	LF	F	S	Z	LH	stroke													
UD3s	FS R40	Rod	Alu	measurement centerline upper fitting (without toggle) - intersection point stay/deck	254	215	128	50	1830	77	depends on upper fitting dimensions	221	100														
		Carbon	246		140	220																					
		PBO	Carbon		***	***		***																			
		EC6	Carbon		***	***		***																			
	FS R50	Rod	Alu		254	215		50						1885	112	156	234	150									
		Carbon	246		140	220																					
		PBO	Carbon		***	***		***																			
		EC6	Carbon		***	***		***																			
	FS R5H MKIII	Rod	Alu		254	215		50											185	50	1885	112	194	194	200		
		Carbon	246		140	220																					
		PBO	Carbon		***	***		***																			
		EC6	Carbon		***	***		***																			
UD4s	FS R50	Rod	Alu		294	215	50	206				2105	140													302	369
		Carbon	326		170	220																					
		PBO	Carbon		***	***	***																				
		EC6	Carbon		***	***	***																				
	FS R5H MKIII	Rod	Alu		294	215	50							206	2105	140	302	369									
		Carbon	326		170	220																					
		PBO	Carbon		***	***	***																				
		EC6	Carbon		***	***	***																				
	FS R6H MKIII	Rod	Alu		294	215	50												206	2105	140	302	369				
		Carbon	326		170	220																					
		PBO	Carbon		***	***	***																				
		EC6	Carbon		***	***	***																				
UD5s	FS R6H MKIII	Rod	Alu	340	270	50	206	2105	140	302	369																
		Carbon	390	220	300																						
		PBO	Carbon	***	***	***																					
		EC6	Carbon	***	***	***																					
	FS R7H MKIII	Rod	Alu	340	270	50						206	2105	140	302	369											
		Carbon	390	220	300																						
		PBO	Carbon	***	***	***																					
		EC6	Carbon	***	***	***																					
	FS R8H MKIII	Rod	Alu	340	270	50											206	2105	140	302	369						
		Carbon	390	220	300																						
		PBO	Carbon	***	***	***																					
		EC6	Carbon	***	***	***																					
FS R8L	Rod	Alu	340	270	50	206	2105	140	302	369																	
	Carbon	390	220	300																							
	PBO	Carbon	***	***	***																						
	EC6	Carbon	***	***	***																						
* measurement with adjuster fully down! Max. length = X or LS + stroke																											
** required length to reach the lower stay connection - slidable foil tube supplied with alu foils only																											
*** no standard - to be confirmed																											

For the calculation of the required stay length D and the required foil length B use the values in the table above. Please use the following calculations to determine the measurements. F means sail feeder height. Ensure that your furler is not customized. All measurements with real time adjuster fully down. All measurements in mm.

**Note!**

All measurements with real time adjuster fully down.

 $B = AUD - TL - T - LS$

with

AUD= length reference, measured from cl / deck cut out to the cl of top terminal pin. Note: Please refer to the notes mentioned in the “toggle” chapter.

TL= terminal length, depending on your topterminal

T= bottom deduction, see table above

LS = top deduction, see table above

B = required foil length including foil adapter tube. Sliding torque tubes in lowest position!

 $C = P - B$

with

C = the foil package has to be shortened by this measurement.

B = see text above

P = unshortened (shipped)foil length, see packing list

The required stay length D is calculated as following:

 $D = AUD - X$ **Note!**

The provided rod nose has to be in the right direction on the bottom end of the stay when using a rod headstay. Ensure that the nose is on the stay before the cold head is pressed.

4.2 Tools required for assembly

Before assembling the reefing system, ensure that you have all the tools necessary. In addition to the allen keys enclosed with the system you will need:

- screwdriver
- cross head screwdriver
- drill
- 3.0 mm drill bit for R10 to R20 and
- 4.0 mm drill bit for R30 to R40
- 4.0 mm drill bit for S1 to S3
- 5,2mm drill bit for R50 and R5 to R8
- M6 thread drill for R50 and R5 to R8
- hacksaw
- sharp knife

4.3 Foil size

The next steps of foil assembly are depending on the foil size. Please jump to the chapter which describes the assembly of your foil size!

R10 up to R40, including foil reinforcement (please see note below)
R50, R5 up to R8



Note!

Please follow the description for the assembly of your foil size!


Note!

If your system is equipped with a R10 up to R40 foil reinforcement, please note the reinforcement chapter behind the foil assembly chapter.

4.4 Foil assembly from R10 up to R40

4.4.1 Preparation of the top cap

Insert both half of the top cap into the top section and carefully drill a pilot hole (see table for d in the chapter preparations) on each side for the screws provided. Remove the top cap for installation later.




Required drill bit diameter for top cap assembly

R10	3 mm
R20	3 mm
R30	4 mm
R40	4 mm


4.4.2 Shortening the top foil

Shorten one of your 3000mm standard foils by the measurement C. This shortened foil is now your top foil.



4.4.3 Shortening the top hose

Shorten the top hose by the measurement C..



Assembling the furling unit

4.4.4 Assembly of bushings and spacer tubes

If your system was delivered with reinforced profiles please continue with the next chapter for the assembly procedure:

Rod headstay:

After assembly of the eye terminal and before cold heading the rod, slide the bushes and spacer tubes onto the forestay from the bottom to the top as shown in the diagram. Fit the 7 top bushes first and then the top spacer which was cut to match the top section. It is important that the order and numbers of bushes and spacer tubes are fitted as shown in the diagram. This will ensure that the 500 mm spacers, which are marked red, will be correctly positioned for each foil section join. With some systems, depending on the total section lengths supplied, there may be a 1500 mm long section of foil. The bush and tube spacings for this particular section are fitted to the lower end of the stay, as illustrated, ensuring that it is situated on final assembly immediately above the feeder (bottom) section. Finally, after fitting all the bushes and spacer tubes in the correct sequence, fit the bushings and hoses for the feeder section according to the following diagram.


Wire headstay:

After fitting the lower terminal and before assembly of the top terminal, the bushes and spacer tubes are fitted from the top to the bottom as shown in the diagram above. Fit the bushings and hoses for the feeder section first. It is important that the order and numbers of bushes and spacer tubes are fitted as shown in the diagram. This will ensure that the 500 mm spacers, which are marked red, will be correctly positioned for each foil section join. With some systems, depending on the total section lengths supplied, there may be a 1500 mm long section of foil. The bush and tube spacings for this particular section are fitted to the lower end of the stay, as illustrated, ensuring that it is situated on final assembly. Finally after fitting all bushes and spacer tubes in the correct sequence, fit the top spacer and 7 bushes to the top end. Before fitting the top terminal, ensure that all the bush spacing is correct and will match the foil join positions.



Note!

For foils R10 and R20 two additional bushings have to be placed at the bottom stay end.



Assembling the furling unit

4.4.5 Foil assembly / split foil connectors


After the assembling of the bushes and hoses on the forestay and the shortening of the top profile start to assemble the profiles.

Sequence of the profiles:

Top section -- x Standard
section 3000 -- x

Standard section 1500 -- Lower
section


From the bottom end of the stay, slide on and feed the top profile along to the top end of the stay. When in place, assemble a pair of split join sleeves over the stay at the spacer tube, marked red, directly under the top section (fig. 1). Insert a stainless steel plate (1) into the recess on the top half of the join sleeve and make sure that the holes of the plate and the join sleeve are on the same side. Push the join sleeve half of its length into the upper foil section (2). (fig. 2).



Note!

Ensure that the holes of the connector plate and foil are aligned. Otherwise the Tuff-Lock screws won't fit.

Secure the join sleeve with 2 tuff-lock screws (fig. 3). Slide the next piece of extrusion from the bottom end over the stay up to the join sleeve. Insert the lower stainless steel plate into the recess in the join sleeve (fig. 3). Slide the foil section over the join sleeve (fig.4) until it butts cleanly with the upper section and then secure it with 2 tuff-lock screws (fig.5). This process is repeated until all the foil sections are in place.



4.5 Installation of the foil reinforcement (optional)

4.5.1 Preparation of the headstay

In some cases a reinforcement of the feeder section is required. The differences regarding the assembly are described in this chapter. If your stay is already assembled, begin as followed:

Unscrew the two security screws of the lower section (fig01) and slide it down off the stay (fig02).

Disassemble the marked bushes and hoses (fig03), they are no longer needed. .




Bild 1 / fig. 1




Bild 2 / fig. 2




Bild 3 / fig. 3

Assembling the furling unit

4.5.2 Reinforcement assembly

Place the reinforcement on the stay in the area, in which you have disassembled the bushes and hoses (fig04)




Bild 4 / fig. 4

Thread one end of the small rope through the two holes at the bottom end of the reinforcement and make a loop to knot it.

Thread the other end of it from the top to the bottom end of the lower section. .




Bild 5 / fig. 5

Assembling the furling unit

Slide the lower section onto the stay and the reinforcement up to the following section. During this action hold the reinforcement in place at the bottom end of the stay using the small rope. (fig 06)





Bild 6 / fig. 6

Remove the small rope from the reinforcement. Insert the lower split bearing into place as shown in the drawing. Push the stay through the furler and insert the lower foil section into the flange. Secure the foil in the flange with the two cap screws provided. (fig07)


Then secure the stay inside the furler, please follow the description in the furler manual.



4.6 Foil assembly R50, R5 up to R8


4.6.1 Shortening the top foil

Shorten one of your 5980mm standard foils by the measurement C. This shortened foil is now your top foil.



4.6.2 Preperation of the top cap

Insert both halves of the top cap into the top section and carefully drill a pilot hole dia 5,2mm on each side for the screws provided. Remove the top cap for installation later. Make a thread of M6 in both of the top cap halves and suit the boreholes for the counter-sunk screws.



Assembling the furling unit

4.6.3 Sliding the top foil onto the stay

Step 1

From the bottom end of the stay, slide on and feed the top section along to the top end of the stay. (Fig. 1)

Step 2

There are four possibilities for installation a.) , b.) , c.) or d.) . Which is correct for your application depends on the measurement C, calculated on page 20:

a.) measurement $C < 2150\text{mm}$: Place two big split bushes and two long spacer tubes on the stay. Secure the bushes with tape and push them together into the top section. (Fig. 2) b.) measurement $C > 2150\text{mm}$: Place only one big split bush and only one long spacer tube on the stay. Secure the bush with tape and push them together into the top section. c.) measurement $C > 3850\text{mm}$: You need no bush and no spacer tube for the top section, go ahead with step 3 of the further installation explained on the next page.

d.) measurement $C > 5590\text{mm}$: You need no bush and no spacer tube for the top section. Either you have to cut the join sleeve or you leave out the top section. If you leave out the top section follow the




Fig. 1

Fig. 2

installation on page 24 with step 5.

4.6.4 Fasten a connector on the stay

Step 3:

Put a join sleeve on the stay directly under the top section and assemble one split splice bearing at each end. Fix the splice bearings with the correct delrin screws. (Fig. 3)




Fig. 3

Assembling the furling unit

4.6.5 Inserting a threaded plate

Step 4

Insert a stainless steel plate into the recess on the top half of the join sleeve. Push the join sleeve half of its length into the upper foil section. Secure the join sleeve with the given tuff-lock screws. (Fig. 4)

Step 5

Slide the next piece of extrusion from the bottom end over the stay up to the join sleeve. Insert the lower stainless steel plate into the recess in the join sleeve. Slide the foil section over the join sleeve until it butts cleanly with the upper section and then secure it with the given tuff-lock screws. (Fig. 5)




Fig. 4




Fig. 5

4.6.6 Sliding the remaining foils onto the stay

Step 6




Repeat step 2a to step 5 until all of the foil sections are in place. (you don't have to take measurement C into consideration when repeating step 2a)

Step 7

After fitting the last two big bushes and long spacer tubes (Fig. 6), assemble the lower reinforcement on the stay and fit a split splice bearing on its top end. (Fig. 7)

Step 8

Insert the sail feeder thread plate (not applicable for R50 and R5) into the recess on the reinforcement and push the ready assembled reinforcement completely into the last foil section. (Fig. 8)



Gewindeplatte
entfällt bei der
Verwen-
dung von
R5 Pro-
filen

Thread plate is
not applicable
when using R5
profiles

4.6.7 Assembly of the feeder section

Step 9

Assemble one small split bush and one short spacer tube. Secure the split bush with tape and push them together into the upper foil section (Fig. 9). Repeat this for R50, R5, R6 and R7 three times, for R8 two times. (Fig. 10 to Fig. 12)




Fig. 9




Fig. 10




Fig. 11





Fig. 12

4.7 Assembly of halyard swivel and sail feeder for foils R10 up to R50


When the halyard swivel is on the profile lay the sail feeder in its recess in the foil. Secure it with the clamp and the two provided screws as it is shown on the picture.



4.8 Assembly of the top cap

(as an option)

Ensure that all the delrin bushes are inside the foil section and then insert the top cap into the top profile and secure in place with the two screws provided.




Assembling the furling unit



4.9 removing the hydraulic motor

In particular cases, the hydraulic motor needs to be disassembled prior the furler can be attached to the deck or the chainplate. Release both motor fastening screws (1) and pull the motor (2) out of the furler. The gear is still sealed, so no oil can leak out of the gear. After the furler is installed to the deck, the motor can be reassembled.


deck attached units:



Chainplate attached units:



4.10 Installation of the furler to the deck



The under deck furling unit UD is flanged to the deck. It is bolted to a special threaded ring below deck. Please ensure that the deck is able to tolerate the entire stay load.

The following parts belong to the deck flange assembly:

- Spherical deck flange (1) with installed secondary gear
- Threaded ring (3)
- Bolts (2)

To transmit the high torque from the furler to the deck, it is necessary that the holes of the flange and the threaded backing plate align exactly. We can provide a drilling template on request.




Note!

Under deck furling unit may only be installed to decks with a maximum thickness named in the table below. If the deck thickness is larger, the furler may be damaged due to stay sag.

Max. deck thickness: :


UD-2	UD-3	UD-4	UD-5
15 mm	25 mm	35mm	40 mm

Components of the deck flange:



4.11 Assembly of stay, foils and furler

4.12 Connection of stay and furler



After the secondary gear unit was installed to the deck, the headstay can be connected to the furler.

Apply Tef-Gel or similar to the thread of the rod nose. Screw the rod nose (1) into the connector until no thread is visible above the connector (2). Secure the connection with both provided grub screws (3).



Note!

After the nose is screwed entirely into the connector, no thread may be visible above the connector.

**Note!**


Risk of seizing of the thread!

Apply Tef-Gel or similar to the thread before the nose is screwed into the connector!

4.13 Connection of foils and furler


Please follow the steps below to connect foils and furler.

Make sure that the foil reinforcement (3) is entirely slid into the feeder section. Please note the foil reinforcement chapter of this manual. Now put the key (2) into the referring recess at the bottom of the feeder section. Coat all contact areas with Tef-Gel to avoid corrosion. Secure the key with a thin layer of tape (Tesa or similar).



Assembling the furling unit

Now put the keys (4) into the recesses in the foiladapter(5).
Now slide the adapter (5) into the torque tube (6).




Assembling the furling unit

Now the entire torque tube assembly (9) can be slid onto the foil. Please make sure that the key is in its position on the feeder section.



Make sure that the spacer ring (10) is on its position on the foil drive. Now the stay can be connected to the furler. Please refer for the stay connection to the referring chapter of this manual.


Now put the keys (11) into the keyways and slide the entire assembly onto the foil spline of the furler.



Assembling the furling unit

Now foils and torque tube can be secured with the provided screws (13) and (14).


Please apply Tef-Gel to avoid corrosion.



Note!

Apply Tef-Gel to all connections to avoid corrosion between all joined parts.

4.14 Configuration of the head



Halyard leads

To prevent the genoa halyard from twisting around the forestay, the angle between forestay and halyard must be at least 10 ° (fig. 1). If this requirement

Assembling the furling unit

is not fulfilled, a halyard lead must be fitted.

(fig.3)

Position of the halyard swivel If the boat is equipped with more than one headsail, each one should be given equal luff length so that the halyard swivel will be located at the same level when the sail is hoisted. It is imperative that the halyard shackle is always at the same position at the top, i.e. approx. 20cm from the halyard sheave. If the sails are not cut to the same length, a wire pennant must be fitted to ensure that the halyard swivel is always at the same height when the sail is hoisted. (fig 2)



Note!

The angle between halyard and headstay has to be at least 10°. If the angle is less than 10° a halyard lead has to be installed.

4.15 Valve configuration of the motor


The UD series furlers should be controlled by a 4/3 directional control valve with symbol 4. In dependence of the power pack flow rate, a throttle valve is required in line P. The oil flow should not exceed the number mentioned in the spec sheet at the end of this manual, otherwise the hydraulic drive could be damaged. From UD-4 up, a load control valve is required in the line from the directional valve to the hydraulic drive. We recommend to place this valve block close to the hydraulic drive and not direct on the power pack. If you run furlers from UD-4 up without a load control valve, a safe operation is not guaranteed. The required valve block includes two load control valves with a control ratio of $i=10$ and an adjustable control pressure between 70 bar and 175 bar. We offer this load control valve block with an aluminium housing and two valve cartridges as an option. The thread size for the hydraulic line fittings is 1/2". If you like us to deliver this block, please contact us.




Warning!

Exceeding the maximum values of oil flow and pressure may cause damages of the furler. Make sure the max. values named in the spec. sheet at the end of this manual are not exceeded.

Gears up to UD-3



Gears from UD-4 up



4.16 Connection of the hydraulic hoses to the real time adjuster


The Reckmann real time adjuster has a main line (ML) and a control line (in case of an installed po-check valve).

Both protection caps need to be removed from the ports before the hoses can be connected.

Both ports can be identified by their thread size:

ML $\frac{1}{4}$ "

CL $\frac{1}{8}$ "



4.17 Stay adjustment with the real time adjuster

Depending on the scope of supply of your furler, it is equipped with a load control valve. Please see the specification sheet at the end of the manual for this information.

Make sure that both (when the adjuster is NOT equipped with a po-check valve just one) ports are connected properly.



Warning!

The real time adjuster is a tool for stay tension adjustment. Its high load level may cause damages of the foils and sails when not completely disconnected. Release the halyard or ease cunningham before operation of the real time adjuster.

Tensioning the stay:

Pump oil into the main line (ml) port of the adjuster to tension the stay. The po-check valve (if installed) is unlocking in this direction automatically. Information regarding the adjuster stroke can be found in the technical specification table at the end of this manual.



Warning!


Exceeding oil flow and pressure may cause damages of the furler.

Make sure that the max. cont. pressure in the adjuster does not exceed **350 bar (250 bar for UD3)** and the max. oil flow does not exceed 2l/min.

If your adjuster is equipped with a po-check valve, you can make the main line pressure free. The po-check valve will keep the pressure in the adjuster.

Releasing the system

Function diagram of the po-check valve:



If a po-check valve is installed, it has to be unlocked for releasing the stay tension. The piston will be pulled out by the stay load.

To unlock the po-check valve, the control line cl needs to be pressurized. Due to the proportion of area in the valve, the required pressure to unlock the valve can be calculated in the following way:

$$P_{cl} = (p_a / 2,6) + 2,5$$


Due to leakage in the valve, it can be necessary to adjust the pressure in the control line.

4.17.1 Stay adjustment in relation to halyard tension

The real time adjuster is tensioning the stay in relation to the foils. The stay retracts topside of the profiles when tensioned (fig.1) and expands out of the foils when eased (fig. 2). While easing the distance between top end of the foil and the halyard lock enlarges.

Now if neither the halyard nor the cunningham is eased, while the real time adjuster released, the luff of the sail will be loaded.

Assembling the furling unit



When you are operating a halyard lock you need to ease the Cunningham when the real time adjuster is released.

If you do not have a halyard lock you have to ease the halyard.

Please make sure you only adjust the stay while the sail is unfurled.

Operating safe is a simple step by step process, which can be done either with PLC logic or manual.

Please follow these steps to adjust the stay tension:

Tensioning the stay:

1. Unfurl the sail completely
2. Tension stay (without load)
3. Tension Cunningham (without sheet load)

Easing the stay:

1. Unfurl the sail
2. Ease Cunningham (without sheet load)
3. Ease stay (without sheet load)




Tip

Each function should be locked until the previous function is completed or eased/tensioned to a predetermined point/pressure.

Assembling the furling unit

4.18 Installation of the hydraulic manual backup system

Components of the system:




- | | |
|-----------------------------------|-------------------------------|
| 1 Deck ring / winch handle socket | 2 Deck flange |
| 3 Hex key for ratio adjustment | 4 Socket for ratio adjustment |
| 5 Oil filler cap | 6 Oil flush plug |
| 7 Main line plug | |

The Reckmann manual backup drive consists of a manual hydraulic pump which is connected to the hydraulic system of the boat. The Pump is driven by

a standard winch handle. The pump can be installed somewhere below deck or through the deck to be driven from above deck. The pump is made of bronze and is additionally sealed with an epoxy finish against corrosion. The shaft is made of stainless steel.

Installation of the pump:




Slide the pump unit (3) from the bottom side through the deck (1) cut out. Apply Sika-Flex or similar between the deck and the pump to seal the connection. Secure the Pump to the deck with the cap screw (2) and four M8 bolts at the flange.

Hydraulic connection:

Assembling the furling unit

The pump is simply connected to the A and B lines between manifold and furler. Please make sure that a set of po check valves avoids oil flow from the pump into the manifold (pls. see the following diagram). The pump is protected against pressure from the A and B line by an integrated po check valve. There are two possibilities to ensure that the pump is supplied with oil at every time:


The first possibility is an external oil tank with a volume of at least 1l. The tank has to be placed above the pump and is connected to port(1). In this setup, the drain line of the motor of the furler may not be used. This solution has some disadvantages: The pump has to be placed on the same level as the furler, you have to ensure that the tank is always filled and at least you have to make sure that the tank does not leak due to heel of the boat.



We recommend to fill the pump with the oil from the furler drain line. In this setup, the pump can be installed either above nor below the furler in any position. The drainline from the motor is installed at the lower no. 1 port, the line to the tank at the higher no. 1 port.

The A and B lines to the furler have to be installed to the ports (2) in both cases.

Wiring diagram:



Assembling the furling unit

Port sizes of the pump:

For UD-2 and UD-3 furler:

A and B lines: 7/8"-14 UNF (O-ring fitting)
drain line / tank holes 1/4 NPT


For all sizes above:

A and B lines: 9/16"-18 UNF (O-ring fitting)
drain line / tank holes: 1/4 NPT

4.19 Operation of the manual backup


To operate the manual backup you just have to rotate the pump with the help of a standard winch handle which has to be stuck to the socked above deck level. The pump works in both directions, to change the direction of rotation of the furler just rotate the pump in the opposite direction.

If the force on the handle is too large, you can simply adjust the volume per revolution of the pump with the provided hex key: Larger volume per revolution means higher force on the handle but more furling speed. Less volume means less force at the handle and less furling speed.




To adjust the pump volume, simply pull the hex key (1) out and stick it into the socket (2).

Now the pump volume and following that, the ratio of the manual backup drive can be adjusted.




4.20 Additional installation information

The following sketches may help you during the installation of the pump:



4.21 Piston position indicator (as an option)



To report the position of the piston of the real time adjuster to the helmsman, Reckmann uses a special electronic sensor. The sensor is situated at the bottom of the adjuster. It is easily accessible for cleaning or changing. The sensor can be connected to the electronic system available on the yacht, for example B&G Hercules or Hydra servers. The sensor has the following technical specifications:

operating voltage: from 10V up to 30V dc

electric power: 40 mA

output: linear analog voltage / current


0V up to 10V dc, rising characteristic / 4..20 mA rising characteristic

wiring: pin 1: +10 up to +30 V dc (brown)

pin 2: signal, 0 up to 10 V dc / 4..20 mA (white)


pin 3: gnd (blue)

4.22 Pressure sensor (as an option)



As an option we provide a pressure sensing unit to monitor the pressure in the adjuster. This value is corresponding with the load on the stay. The pressure can be measured as long as the adjuster is not in top position. There are two versions of the pressure sensor: one with 0...10V output and one with 4...20mA output. Please find the specs referring to your sensor on the following pages.

Hydraulic connection of the sensor:




Note!

The sensor cannot measure the pressure inside the adjuster when it is fully extended.



Do not fully extend the adjuster to ensure a proper function of the sensor.

Assembling the furling unit



dimensions of the sensor:



Wiring:
PT3540 (mA output)



PT9540 (Voltage output)



Specifications:

	PT3540	PT9540
Operating Voltage	8,5 ... 36V	16V ... 36V
Reverse polarity protection	yes	yes
Analogue output	4...20mA	0...10V
Pressure rating	600 bar	600 bar
Bursting pressure	1600 bar	1600 bar
Connection	M12	M12
Materials	316L / 1.4404	316L / 1.4404

5 specifications

UD3s

		foils		R40	R5	S3	S4/S4.5
stay and sails	headstay	rod	[-]	30 up to 48	48 up to 60	30 up to 48	48 up to 60
		wire	[mm]	14 up to 16	16	-	-
	max. stay length		[m]	27	33	27	33
	max. sail area		[m ²]	175	230	175	230
	max. sheetload		[kg]				
	max. halyard load		[kg]				
	max. tack load		[kg]				
hydraulic specifications	furler	max. pressure	[bar]	140			
		at torque	[Nm]	448			
		max. oil flow	[l/min]	17			
		at rpm	[1/min]	29			
		thread ML	[-]	R3/8			
		thread DL	[-]	-			

UD3s

Adjuster	function		[RT / DS]	RT
	stroke		[mm]	100
	max. pressure		[bar]	250
	at stayload		[kg]	12175
	max. swl stay		[kg]	-
	thread ML		[-]	1/4"
	thread CL		[-]	1/8"
	Fitting ML	Parker		6F42EDMXSS
	Fitting CL	Parker		4F42EDMXSS
	po-check valve		[-]	RHC1

UD4sc

		foils		R5	R7	S5	S5.5
stay and sails	headstay	rod	[-]	60 up to 76	76 up to 91	60 up to 76	76 up to 91
		wire	[mm]	19	21	-	-
	max. stay length		[m]	36	38	36	38
	max. sail area		[m²]	275	320	275	320
	max. sheetload		[kg]				
	max. halyard load		[kg]				
	max. tack load		[kg]				
hydraulic specifications furler	max. pressure		[bar]	175			
	at torque		[Nm]	960			
	max. oil flow		[l/min]	30			
	at rpm		[1/min]	39			
	thread ML		[-]	R3/8'			
	thread DL		[-]	-			

UD4sc

Adjuster	function	[RT / DS]	RT
	stroke	[mm]	150
	max. pressure	[bar]	350
	at stayload	[kg]	-
	max. swl stay	[kg]	-
	thread ML	[-]	1/4'
	thread CL	[-]	1/8'
	Fitting ML	Parker	6F42EDMXSS
	Fitting CL	Parker	4F42EDMXSS
	po-check valve	[-]	RHC 1/0



UD5sc

		foil		R6	R7	S6	S6.5/S7
stay and sails	headstay	rod	[-]	91	115 up to 150	91	115 up to 150
		wire	[mm]	26	28 up to 32	-	-
	max. stay length		[m]	40	50	40	50
	max. sail area		[m²]	350	500	350	500
	max. sheetload		[kg]				
	max. halyard load		[kg]				
hydraulic specifications	max. tack load		[kg]				
	furler	max. pressure	[bar]	175			
		at torque	[Nm]	1102			
		max. oil flow	[l/min]	40			
		at rpm	[1/min]	44			
		thread ML	[-]	R3/8'			
		thread DL	[-]	-			

UD5sc

Adjuster	function		[RT / DS]	RT
	stroke		[mm]	200
	max. pressure		[bar]	350
	at stayload		[kg]	-
	max. swl stay		[kg]	-
	thread ML		[-]	1/4'
	thread CL		[-]	1/8'
	Fitting ML	Parker	6F42EDMXSS	
	Fitting CL	Parker	4F42EDMXSS	
	po-check valve		[-]	RHC 1/0

5.1 Reckmann aluminium foil sections



Größe / size	Nut / groove	G (mm)	O (mm)	A (mm)	B (mm)
R10	double	6,4	2,3	31,4	24,1
R20	double	6,4	2,3	35,8	28,8
R30	double	7,5	3,0	45,5	36,1
R40	double	7,5	3,0	49,1	38,7
R50	double	8,0	3,5	54,0	42,0
R5	single	7,5	3,5	60,0	47,0
R6	single	7,5	3,5	72,0	60,0
R7	single	7,5	3,3	85,0	72,0
R8	single	8,0	3,2	107,0	93,0

6 Dealer network and service stations

Denmark

Southern Spars	With Marine A/S
Torben Jacobsen	Leangbutka 31
Bergensvej 6	N - 1392 Vette
DK-6230 Rødekro	T.: +47 66 79 89 14
T.: +45 74 620060	F.: +47 66 79 74 83
F.: +45 74 630543	info@withmarine.no
info@southernspars.com	

Quantum Sail Design Group	Elvstrøm Sobstad Norge A/S
Jan Hansen	Espen Kamperhaug
Amager Strandvej 50	Sjøsenteret Vallø-PO Box 148
DK-2300 København	N - 3166 Tolsvrød
T.: +45 7026 1296	T.: +47 3341 4141
F.: +45 3296 1276	F.: +47 3341 4142
	info@elvstrom-sobstad.no

Sweden

Sellpower Nordic AB
Magnus Wosse
Baggakersgatan 4a
SE - 43153 Mölndal
T.: +46 31 761 85 80
F.: +46 31 876 535
info@sellpower.se

Norway

Southern Cross Spars A/S
Sandviksvn 120
N - 1363 Høvik
T.: +47 959 77482
F.: +47 9720 18 18
ed@southerncross.no

United Kingdom

HYS Rigging
Dennis Fisher
Port Hamble
GB– Hampshire SO31 4NN
T.: +44 2380 454111
F.: +44 2380 455682
rigging@hambleyachtservices.co.uk

Netherlands

A+ Rigging Nederland B.V.
Zeldenrust 7
NL-1671 GW Medemblik
T.: +31 227-544096
F.: +31 227-544158
info@aplusrigging.nl

Italy

G&G Rigging srl
Walter Giovanelli
Via Mazzini 33
I–20099 Sesto S. Giovanni
T.: +39 02 454 811 90
F.: +39 02 365 138 95
info@gegrigging.com

France

Grément Import
13 Rue du Chêne Lassé - BP
F–44803 Saint - Herblain
T.: +33 2 28 03 01 01
F.: +33 2 28 03 19 91
bb@greementimport.fr

Spain

Yachttech
Oliver Blume
C /Ca'n Valero 40, Nave
E–07011 Palma de Mallorca
T.: +34 971 200052
F.: +34 971 296504
info@yachttech.net

Dealer network and service stations

Croatia

ASPAR Rigging
Luzine bb
CRO-51000 Rijeka
T.: +385 51 674 031
F.: +385 - 51 674 031
aspar-rigging@ri.t-com.hr

Sinera Rigging
Psg. Joan de Borbó 92
E-08039 Barcelona
T.: +34 932 254 934
F.: +34 932 251 949
info@sinerarigging.com

Slovenia

DNA d.o.o.
Miha Spendal
Kantetova 85
1000 Ljubljana
T.: +386 41 730 970
F.: +386 12776 606
dnamsp@siol.net

Malta

XS Marine Ltd.
James Xuereb
26, Paul Borg Str.
Attard, Atd 2632
T.: +356 7900 9300
F.: +356 2141 3894
info@xs-marine.com

Greece

Kafetzidakis Sails
Kostas Kafetzidakis
90 Tzavella
GR-18533 Piraeus
T.: +30 210 413 74 38
F.: +30 210 413 16 24
info@kafetzidakis.gr

Turkey

UTL / Skiper
Muhane cad. Akce sokak no 10/4
Karakoy
Istanbul
T.: +90 212 292 90 98
F.: +90 212 292 91 93
info@skiper.org

New Zealand

Southern Spars Ltd.
15 Jomac Place
Avondale
NZ-1026 Auckland
T.: +64 9 8457200
F.: +64 9 3583309
info@southernspars.com

New Zealand Rigging Ltd.
31 Woodside Ave - Northcote
NZ– Auckland
T.: +64 9 480 8090
F.: +64 9 480 9190
bart@nzrigging.com

Dealer network and service stations

Australia

Riggtech
Phill Bate
Royal Prince Alfred Yacht Club
2/16 Mitala Street,
P.O. Box 812
AUS - 2106 Newport Beach
T.: +61 2 9997 8100
F.: +61 2 9979 6848
info@riggtech.com.au

Caribbean

Antigua Rigging Ltd.
Stan Pearson
English Harbour
Antigua, West Indies
T.: +1 268 4638575
F.: +1 268 5621294
info@antiguarigging.com

FKG Marine Rigging
Kevin Gavin
37 Wellington Road
99998 St. Maarten
Netherlands Antilles
Tel. +599 544 4733
Fax. +599 544 2171
kevin@fkg-marine-rigging.com

USA

Nance and Underwood
262 Southwest 33rd st.
USA - FT Lauderdale, FL 33315
T.: +1 954 764 6001
F.: +1 954 764 5977
nanceandunderwood@aol.com

Euro Marine Trading, Inc.
Siebe Noordzy
62 Halsey Street, Unit M
USA– Newport, RI 02840
T.: +1 401 849 0060
F.: +1 401 849 3230
info@euromarinetrading.com

Florida Rigging & Hydraulics, Inc.
3905 Investment Lane, Suite 9
USA– Riviera Beach, FL 33404
T.: +1 561 8637444
F.: +1 561 8637711
cehinger@rigginghydraulics.com

Offshore Spars
Mike Feldmann
50200 E.Russell Schmidt Blvd.
USA– Chesterfield, MI 48051
T.: +1 586 598 4700
F.: +1 586 598 4705
mike@offshorespars.com

Rigworks Inc.
Ray Pope
2540 Shelter Island Drv.
USA - San Diego , CA 92106
T.: +1 619 223 3788
F.: +1 619 223 3099
info@rigworks.com

Rigg Pro
14 Regatta Way
USA - Portsmouth, RI 02871
T.: +1 401 683 2151
F.: +1 401 683 7878
john.b@southernspars.com

7 Index

- Assembling the furling unit 18
- Assembly of bushings and spacer tubes 26
- Assembly of halyard swivel and sail feeder for foils R10 up to R50 50
- Assembly of stay foils and furler 55
- Assembly of the feeder section 49
- Assembly of the top cap 51
- Calculation of stay and foil length 19
- components of the manual backup drive 16
- Configuration of the head 63
- Connection of the hydraulic hoses to the real time adjuster 66
- Connection of foils and furler 57
- Connection of stay and furler 56
- Dealer network and service stations 88
- Fasten a connector on the stay 44
- Foil assembly / split foil connectors 31
- Foil assembly from R10 up to R40 23
- Foil assembly R50, R5 up to R8 38
- Foil size 22
- How to use this manual 10
- Important remarks 11
- Inserting a threaded plate 46
- Installation of the foil reinforcement 32
- Installation of the furler to the deck 54
- Installation of the hydraulic manual backup system 72
- Introduction 5, 8
- Maintenance of the furler 15
- Maintenance to be carried out by a Reckmann service partner 15
- Maintenance to be carried out by the customer 15
- Packing list 5
- Piston position indicator (as an option) 79
- Preparation of the headstay 32
- Preparation of the top cap 23
- Preperation of the top cap 40
- Pressure sensor (as an option) 80
- Product description 16
- Reckmann aluminium foil sections 86
- Reinforcement assembly 35
- removing the hydraulic motor 52
- Required drill bit diameter for top cap assembly 23
- Shortening the top foil 24, 38
- Shortening the top hose 25
- Sliding the remaining foils onto the stay 47
- Sliding the top foil onto the stay 42

specifications 84

Stay adjustment in relation to
halyard tension 69

Stay adjustment with the real time
adjuster 68

Toggle 13

Tools required for assembly 22

Valve configuration of the motor 65